

AVL Looms, Inc.

IDL DROPWIRE INSTALLATION

1. Mount the Horizontal Brackets onto the Axle at either side of the Dropwire Unit.
2. Using the four bolts from the Hardware Pack, install one Horizontal Bracket at the outside of each Rear Vertical Support, in two horizontally aligned holes which are located near the Separation Roller Brackets.
3. Locate the Power cord, among the other bundled cords coming out of the PCL Box. It has a round terminal with a red button and will fit on two brass prongs located at the top of the rear, right corner.

