Workshop Dobby Loom Raddle Placement

Note: Holes for metal rod should be 1/4" and not 17/64"

New Hole centered 1-3/4 " from end of raddle

Original

Hole -



New Hole centered 1-3/4 " from end of raddle

Original Hole

Hole centered 6-7/8" from end of castle



Hole centered 1-3/4" from end of castle