

2360 Park Avenue, Chico, California 95928-8305 Phone: 530-893-4915 Fax: 530-893-1372 www.avlusa.com

Soft Grip Cloth Beam Cover Installation

- 1. You will wrap your new Cover directly onto your Cloth Beam. You won't need to remove the existing cover.
- 2. Begin at the left end of the Beam.
- 3. With the rubber side of your cover facing out, place the point of the diagonal cut against the left edge of the Beam. This will cause the strip of Cover to spiral around the beam. Hold it in place with a piece of masking tape.
- 4. It is important that you keep the edge of the Cover flush against the end of the Beam as you begin. Slowly wind the Cover on the Beam.
- 5. Continue to wind the cover on, taking care to keep each successive wrap pushed tightly against the last.
- 6. When you have come to the end of the Beam, secure the last of the cover with more tape. If the cover is a bit too long, you may want to trim it.
- 7. To secure the edges. Use tape to wrap all the way around the right and left edges of the beam.